



**B.M. MACCHINE UTENSILI s.r.l.**

Via Edmondo De Amicis, 146 - 10093 Collegno (TO) - ITALY

Tel: (0039) 011-403.11.24 / 011-403.15.79 - Fax: (0039) 011 403.13.28

www.bmtorino.it - bm@bmtorino.it

IT 07417070013

**OMLAT**  
Code 5617



**CHUCK - DIVIDING HEAD**

**HUSILLO - DIVISOR**

<b>Electrospindle</b>	Type	Tipo	<b>Electrohusillo</b>
Serial number	<b>1132</b>		Matrícula
<b>Electrospindles OMLAT - Movement adjustment</b>	Notes	Notas	<b>Electrohusillos OMLAT - Regulación desplazamiento</b>

The characteristics, data, measurements and photos provided here are not binding  
Características, datos, medidas y fotos no suponen compromiso ninguno