



**B.M. MACCHINE UTENSILI s.r.l.**

Via Edmondo De Amicis, 146 - 10093 Collegno (TO) - ITALY

Tel: (0039) 011-403.11.24 / 011-403.15.79 - Fax: (0039) 011 403.13.28

www.bmtorino.it - bm@bmtorino.it

IT 07417070013

**OMLAT**  
Código 5617



**HUSILLO - DIVISOR**

**CHUCK - DIVIDING HEAD**

<b>Electrohusillo</b>	<b>Tipo</b>	<b>Type</b>	<b>Electrospindle</b>
<b>Matrícula</b>	<b>1132</b>		<b>Serial number</b>
<b>Electrohusillos OMLAT - Regulación desplazamiento</b>	<b>Notas</b>	<b>Notes</b>	<b>Electrospindles OMLAT - Movement adjustment</b>

Características, datos, medidas y fotos no suponen compromiso ninguno  
The characteristics, data, measurements and photos provided here are not binding